

kit KWR5004

ASSEMBLY INSTRUCTION

- 1) Remove old WASH / RINSE arms from DISHWASHER
- 2) Use a size 19 hex socket wrench to remove the old pins from the lower and upper supports of the dishwasher
- 3) Assemble the new pins screwing with the same tool and applying before some anti-unscrewing glue, like LOCTITE 270, on the thread.
- 4) Assemble the other components as showed below

